





SPARE PARTS & DISASSEMBLY RESERVDELAR & DEMONTERING

ARCTIC





SPARE PARTS & DISASSEMBLY RESERVDELAR & DEMONTERING

ARCTIC

Part No.	Description	Beskrivning	Material	Material	Article No.
1	Seat part	Sits och rygg	Wood	Trä	-
2	Hexagon screw M8x30	Sexkantsskruv M8x30	Metal	Metall	67068
3	Hexagon screw M8x55	Sexkantsskruv M8x55	Metal	Metall	-
4	Frame	Ram	Metal	Metall	-



REPAIR

Carefully remove the broken part and install the new one in place using appropriate tools and fittings according to the assembly and disassembly instructions. Contact AJ Products for spare parts.

RECYCLING

To disassemble the furniture for proper recycling, start by removing all screws and fasteners. Then, separate the materials, such as wood, metal, and fabric, and take them to the appropriate recycling facility.



REPARATION

Ta bort den trasiga delen och montera den nya på plats med lämpliga verktyg och beslag enligt monterings- och demonteringsanvisningarna. Kontakta AJ Produkter för eventuella reservdelar.

ÅTERVINNING

För att demontera möbeln för återvinning, börja med att ta bort alla skruvar och fästordningar. Separera sedan materialerna, såsom trä, metall och tyg, och lämna dem på respektive återvinningsanläggning.